

MYLO WITH COVERS

THIS DOCUMENTS DESCRIBES HOW MYLO AND DIFFERENT TYPES OF POOL COVERS CAN CO-EXIST

POOL MANUAL COVERS- WITH ROLLER OR WITH BUCKLES

If the roller is far from the edge of the pool, the cover can go just over MYLO (see photo number 1).

In picture number 2, the wheels are too close to the edge of the pool for covering MYLO. In such a case you can stop the cover about 4 inches before it reaches the end of the pool so you don't have to take MYLO out every time the pool is not in use.


In picture number 3 and 4 - MYLO can be installed easily, and the cover will pass over without interruption.



2



Manual Safety Cover



4

MYLO WITH COVERS

SOLAR HEATING COVER

Such covers (see picture 5) are usually flexible and will not have a problem co-existing with MYLO.



5

Automatic Safety Cover



6

SLATED COVER AND ELECTRONIC INNER INSTALLATION

With such covers (pictures 6, 7, and 8), there are two options:

1. Stop the cover about 4 inches before the end.
2. Take out MYLO every time you finish using the pool.

7

Electric Inner Installation



Slated Cover



8

MYLO WITH COVERS

MANUAL OR ELECTRONIC INNER INSTALLATION BY SHAPE

Order the cover after purchasing MYLO; this way the cover installers will be able to cut the cover exactly in the shape of MYLO to fit in the corner of the pool (pictures 9 and 10).



TELESCOPIC COVER

If the track on which the cover travels is wider than the edge of the pool by about 12 inches, MYLO will be able to be connected all the time and the cover will pass over it. If the electric cable of MYLO cannot pass under the cover, then it will be necessary to disconnect the cable while the pool is not in use (picture 11).

